

Boaters' Guides


A note about the data

These guides list information we currently have on our facilities, dimensions and navigation guidance, based upon local knowledge and expertise. Whilst we anticipate that this data is reasonably accurate, we cannot guarantee its precision. Therefore, this data should only be used as a helpful guide and you should always use your own judgement taking into account local circumstances at any particular time. If you spot something wrong, please let us know canalrivertrust.org.uk/contact-us

Key to facilities

- Winding hole (length specified)
- Winding hole (full length)
- Visitor mooring
- (i) Information and office
- Dock and/or slipway
- Slipway only
- S Services and facilities
- (5) Water point only

Grand Union Canal Leicester Line



Navigation notes

Grand Union Canal

Berkhamsted to Braunston: Boats up to 14ft 3in beam may be able to navigate this section, but some bridges have low arches or restricted width below water level. Locks are more than 14ft wide so two narrowboats can safely share. Boats over 7ft beam must make special arrangements for passage of Blisworth and Braunston tunnels. Contact the Trust on 03030 404040.

Grand Union Canal Leicester Line

Norton Junction to Foxton Locks: Occasionally, craft of full 7ft beam may experience difficulty in Foxton Locks.

Grand Union Canal

Braunston Tunnel: Wide-beam boats must book passage in advance. Follow tunnel safety requirements.

Grand Union Canal Leicester Line

Husbands Bosworth Tunnel: Follow tunnel safety requirements.

Lock 1, Watford Bottom Lock; and Lock 2, Watford Locks; and Lock 3, Watford Locks; and Lock 4, Watford Locks; and Lock 5, Watford Locks; and Lock 6, Watford Locks; and Lock 7, Watford Locks: See lock keepers before entering flight during British Summertime. Check published opening hours.

Crick Tunnel: Follow tunnel safety requirements.

Services & facilities

Grand Union Canal

Buckby, top lock: Water, Elsan disposal, 1 toilet, refuse disposal. Canal & River Trust key required.

Grand Union Canal Leicester Line

- North Kilworth Wharf: Refuse disposal. Offside, in marina.
- Welford Wharf: Water, Elsan disposal, 3 toilet, refuse disposal. Canal & River Trust key required.
- 5 Yelvertoft, Br 19: Water, refuse disposal.
- 6 Crick Wharf: Water, Elsan disposal, refuse disposal. Canal & River Trust key required. Offside.
- Watford Top Lock: Water, Elsan disposal, toilet, refuse disposal. Canal & River Trust key required.
- Watford Bottom Lock: Water. 8 Canal & River Trust key required.

Maximum Dimensions

Norton Junction to Foxton

Length:	21.79m (71ft 6")
Beam:	2.12m (6ft 11")
Draught:	1m (3ft 3")
Headroom:	2.28m (7ft 6")

Foxton to Kings Lock

Length:	21.94m (72ft)
Beam:	3.05m (10ft)
Draught:	1m (3ft 3")
Headroom:	2.13m (7ft)

Kings Lock to Leicester

24.1m (79ft)
3.05m (10ft)
1m (3ft 3")
2.13m (7ft)


Visitor moorings

Grand Union Canal

1 Buckby: Maximum 48 hours and 14 days.

Grand Union Canal Leicester Line

- 3 Welford, short-stay: Maximum 48 hours.
- 4 Welford: Maximum 14 days.
 - Yelvertoft: Maximum 14 days.
- Crick visitor moorings: Maximum 14 days.



Navigation notes

Kilby Bridge to Debdale: All this length is a Site of Special Scientific Interest.

Foxton Junction to King's Lock, Leicester: Headroom is more limited for boats of more than 10ft 6in beam, and especially so approaching the maximum beam. It will be necessary for such boats to proceed with extreme caution. The channel width is restricted in some places, and broadbeam boats may have difficulty passing other boats.

Saddington Tunnel:

Widebeam passage must be booked 48 hours in advance tel: 03030 404040.

Locks & bridges

Bridge 4, Foxton Swing Bridge:

Please leave this padlocked swing-bridge exactly as you found it.

Lock 17, Foxton Staircase; and Lock 16, Foxton Staircase; and Lock 15, Foxton Staircase; and Lock 13, Foxton Staircase; and Lock 13, Foxton Staircase; and Lock 12, Foxton Staircase; and Lock 10, Foxton Staircase; and Lock 8, Foxton Staircase; and Lock 8, Foxton Staircase: See lock keepers before entering flight during British Summertime. Check published opening hours.

Services & facilities


- Foxton Top Lock: Water. Canal & River Trust key required.
- 2 Foxton Site: Elsan disposal, toilet, refuse disposal.
- 4 Market Harborough Basin: Water, Elsan disposal, pump-out, toilet, shower. Canal & River Trust key required. Standard Canal & River Trust card used. Parking and local shops nearby.

Visitor moorings

- 1 Foxton, top lock: Maximum 48 hours.
- 2 Foxton, north of lock: Maximum 48 hours.
- 2 Foxton lock Inn: Maximum 24 hours.
- 3 Foxton Basin: Maximum 48 hours.
- 4 Market Harborough Basin: Maximum 48 hours. Total 50 metres.

Slipways & docks





Locks & bridges

Grand Union Canal Leicester Line

Footbridge; and Bridge 2, Newarke Bridge; and Bridge 1, Mill Lane Bridge; and Bridge 109A: this is a highly used bridge in the centre of Leicester.

Lock 41, Freeman's Lock: large weir on the topside with navigation signs.

Lock 38, Kings Lock; and Lock 37, Blue Bank Lock; and Lock 36, Gee's Lock; and Lock 34, Dunn's Lock; and Lock 35, Whetstone Lane Lock; and Lock 33, Bush Lock; and Lock 32, Ervin's Lock; and Lock 31, Double Rail Lock; and Lock 30, Kilby Lock: Canal & River Trust key required.

River Soar

Bridge 3, West Bridge: this is a highly used bridge in the centre of Leicester.

Bridge 9, Abbey Park Road Bridge: silting up under this bridge due to floodwater.

Services & facilities

Grand Union Canal Leicester Line

 Kilby Bridge: Water, Elsan disposal, pump-out, toilet, shower, parking. Canal θ River Trust Card.

Visitor moorings

Grand Union Canal Leicester Line

1 Kilby Bridge: Maximum 48 hours. Total 100 metres.

River Soar

